

Preparation Checklist

3 STEPS FOR A SUCCESSFUL INSTALLATION



1.) WINDOW TREATMENTS

A water based solution is used to install window film. Please remove all curtains, drapes, or any other window treatments that you don't want to get wet, stained, or ruined. We need unobstructed access to install your film. Pull up blinds and open shutters.

2.) UNOBSTRUCTED SPACE

Please clear a 3 foot area around each window and sill that window film is being installed on. (plants, decorations, pictures, furniture etc.) If the window requires a ladder, a 6ft area needs to be cleared. If you need help moving a piece of furniture on the day of installation let your installer know before hand so we can get a waiver signed.



3.) DUST DUST AND MORE..

We will do our best to minimize contamination during installation but we need your help. Make sure sills and tracks are clean of dust and debris. Clean any air vents in the vicinity of installation. Curtains are usually very dusty and significantly increase the likelihood of airborne contamination. Remove them before installation.



602-699-4992
azwindowfilm.com